


How to turn off generator to check oil

EXAMPLE of
generator

Generator Main Breaker



Controller

- 1) Turn generator breaker OFF
- 2) Press "OFF" or "STOP" controller
- 3) Let unit cool for 5 Mins
- 4) Add oil as needed
- 5) Press "AUTO" on controller
- 6) Let generator run for 2 mins
- 7) Turn generator breaker back ON